

# Datacenter

Air filter selection according to Eurovent guideline

OUTDOOR AIR QUALITY	SUPPLY AIR CLASS				
	SUP1 (HIGHEST)	SUP 2	SUP 3	SUP 4	SUP 5 (LOWEST)
	RECOMMENDED MINIMUM ISO 16890 FILTER CLASS				
	ePM1	ePM1	ePM2,5	ePM10	ePM10
ODA 1	70%	50%	50%	50%	50%
ODA 2	80%	70%	70%	80%	50%
ODA 3	90%	80%	80%	90%	80%

